



Brix Lab
A Division of Brix Group, Inc.
541 Division St.
Campbell, CA 95008
866-787-1810
www.brixcom.com




Home Docking Kit Installation Guide SIR-STRHK1

Box Contents:

After you unpack your SIR-STRHK1, make sure everything here is included:

1 x Home Dock
1 x Power Supply
1 x AC Cord

1 x Antenna
1 x Audio Cable



For the latest information about this and other Streamer products, visit the Brix Web site at: www.brixcom.com. If anything is missing or damaged, or if your SIR-STRHK1 fails to operate, notify your shipper immediately. Streamer recommends that you keep the original packaging in case you need to ship your SIR-STRHK1 in the future.

Safety Precautions



Caution

Take the following precautions to keep the unit in proper working order:

- Installation must be performed according to this installation manual. Streamer is not responsible for issues arising from installations not performed according to the procedures in this manual.
- Use only the included power supply.
- Do not install the unit where it will be exposed to high levels of humidity, moisture, or dust.

NOTE: Use of the included antenna inside a home requires placement at a North-, West-, or East-facing window (depending on where you live). If a proper window location is not available, the antenna must be placed outside the home, away from any overhead obstructions.


Installation in a Home with the SIR-STRHK1 kit (sold separately)

Note: Do not put Streamer in the docking station until you have completed the installation.

1. Plug the audio cable's mini connector into the back of the cradle, as shown. Plug the audio cable's white (L ch.) and red (R ch.) connectors into your audio system. (ex. Aux In)

2. Plug the AC cord into the power supply, then plug the power supply into the back of the cradle. Don't plug the AC cord into a wall outlet until the installation is completed.

3. Plug the antenna into the back of the cradle until it is firmly secure.



Installation in a Home (continued)

4. Due to the paths of SIRIUS satellites over the US, the best location for the antenna in your home depends on where you live. Use the map below as a general placement guideline—some experimentation may be needed to obtain the best results. In major US cities, you may also be able to receive the signal from SIRIUS ground repeaters, which may allow you to place the antenna away from a window. In all cases, since the antenna is weather-proof if necessary you can also locate it outside, clear of any overhead obstructions. (This is especially important if your house has an extended roof or extended window frame structures.)

Section 1: Place the antenna at an EAST-FACING window

Section 2: Place the antenna OUTSIDE, away from any overhead obstructions

Section 3: Place the antenna at a WEST-FACING window

Section 4: Place the antenna at a NORTH- or EAST-FACING window

Section 5: Place the antenna at a NORTH-FACING window

Section 6: Place the antenna at a WEST- or NORTH-FACING window

